

# HOW TO USE PALLET COLLARS INSTRUCTION SHEET

Pallet Collars are extremely easy to use. They help to organise components, improve storage and warehouse efficiencies, utilise static space, segregate pallets and stack multiple pallets.



Simply:

- Open up the pallet collar into a square.
- Place the pallet collar over the edges of the pallet - ensuring the hinge flange slips over the pallet, locking the collar into place.
- Stack pallet collars on top of each other until your desired height is reached.

(Note: instructions are for standard collars)

To install Divider Boards and Brackets:

- Place a metal bracket on each side of the pallet collar where you'd like the board to align.
- Slip the divider board into the metal brackets.
- Place more sets of brackets on the pallet collars and divider boards to break the pallet up into multiple sections.



Australia Wide Sales & Service

[sales@materialshandling.com.au](mailto:sales@materialshandling.com.au) | [www.materialshandling.com.au](http://www.materialshandling.com.au) | 1300 25 84 07

**MATERIALS**  
**Handling** PTY LTD *Working with ease*